

Instructions for Removing Lenstar.

1. Open the shipping box
2. Remove the top cover
3. Remove the brace.
4. Lift the test eye box.
5. Lift the Lenstar carefully.
6. When packing reverse sequence.

**IMPORTANT: SEND TEST EYE OF UNIT WITH LENSTAR. IN MOST CASES WILL HAVE THE SAME SERIAL NUMBER AS THE UNIT. UNIT NEEDS TEST EYE TO OPERATE. USUALLY KEPT IN TOP RIGHT HAND DRAWER.**

