

How to determine if IM camera is connected to my computer.



This system is connected and ready to go.

This system is not connected



This system is connected and ready to go.



This system is not connected