

## Tightening of slit adjust control

The the bottom of the Illumination Tower there is a silver knob on each side:



The knob on the right (without the numbers on it) has a set screw in the center. Tighten this set screw to increase the tension. Do not over tighten it will increase tension on the knobs, too tight and it will hard to turn the knobs.

